



# **FuelCel**

Light weight composite fuel tanks

## **Suzuki TLR 1000**

### Installation instructions

5.1 pounds = 7.75 pounds lighter

1. All though every precaution is taken in the manufacture of your new FuelCel, in house testing procedures unfortunately cannot reproduce the dynamic conditions of the installation on the motorcycle. Under certain conditions of vibration, heat and gasoline, a minute pinhole can develop in rare cases that escape our detection. We are more than willing to repair a leak that might develop so long as the following procedure is done first.
2. Install all necessary plumbing and hardware for the mounting, install on the bike then fuel it to capacity and run at least half of it through by running the engine, BEFORE PAINTING the tank.
3. Field repair procedure as performed by the factory is outline below for latent pinhole migration. (Extremely rare)
4. **FuelCel repairs** can be made in certain instances if you damage your Fuelcel. Generally if 30% of the exterior surface is damaged it will be considered totaled.

#### INSTALLATION INSTRUCTIONS

- **Do not paint** the area where the Fuel pump-flange seals.
- Be careful installing fasteners and do not over torque the Front Mount fasteners, they are made from aluminum alloy.
- Use the stock rubber grommet for the rear hinge mount and side bumpers.
- **The vent is now in the cap.**
- Be sure that the tank is not being rubbed at any point by frame or other hard surface, puncture from abrasion can occur in a short amount of time.
- **WARNING; Composites are not "malleable" like metal, since weight reduction is the main goal of the FuelCel design, rupture of the tank can occur instead of denting.**
- **This Fuel tank is sold without Warranty expressed or implied by the manufacturer and its final suitability for use is determined by the operator of the motorcycle on which it is installed. 12/13/08**

Self repair instructions for latent pinhole/s, Factory procedure.

